


TIME *OF SALE*

Extended Protection



TRAVEL WITH *PEACE OF MIND*



Your vehicle might be running smoothly today, but unexpected breakdowns can happen anytime, often when you least expect them. Problems like engine trouble, transmission failure, or electrical system malfunctions can be costly to fix. While your factory warranty offers initial protection, it has limitations and won't last forever.


That's where the Time of Sale Plan comes in. Available for both new and used vehicles, this extended coverage plan helps pay for repairs on components such as your drivetrain, suspension, air conditioning, and more. This way, you can protect yourself from surprise expenses and drive with confidence.


30 DAY MONEY BACK *GUARANTEE*


TRANSFERABLE COVERAGE


| SELECT THE RIGHT PLAN FOR YOU. | Powertrain | Select Plus | Ultimate |
|--------------------------------|------------|-------------|----------|
| Engine | ● | ● | ● |
| Turbocharger/Supercharger | ● | ● | ● |
| Transmission | ● | ● | ● |
| Transfer Case | ● | ● | ● |
| Drive Axle | ● | ● | ● |
| Front Wheel Steering | | ● | ● |
| Brakes | | ● | ● |
| Electrical | | ● | ● |
| Air Conditioner | | ● | ● |
| Fuel System | | ● | ● |
| Front & Rear Suspension | | ● | ● |
| Heating/Cooling System | | ● | ● |
| Emission System | | ● | ● |
| Electric/Hybrid Vehicles | | | ● |
| Ultimate Parts Group | | | ● |


SCHEDULE OF *COVERAGE* includes parts and labour for the following components:

|  ENGINE | Powertrain | Select Plus | Ultimate |
|--|------------|-------------|----------|
| Cylinder block & all internal lubricated parts contained within the engine | ● | ● | ● |
| Cylinder Heads | ● | ● | ● |
| Pistons & Piston Rings | ● | ● | ● |
| Connecting Rods & Bearings | ● | ● | ● |
| Crankshaft & Crankshaft Main Bearings | ● | ● | ● |
| OHC Carriers | ● | ● | ● |
| Cover & Module | ● | ● | ● |
| Camshaft & Camshaft Bearings | ● | ● | ● |
| Cam Followers | ● | ● | ● |
| Timing Chain/Belt (unless the timing belt was not replaced when recommended by the manufacturer) | ● | ● | ● |
| Timing Gears | ● | ● | ● |
| Timing Chain Cover | ● | ● | ● |
| Timing Chain Tensioners | ● | ● | ● |
| Timing Chain & Belt Guides | ● | ● | ● |
| Timing Belt Pulley | ● | ● | ● |
| Engine Serpentine Belt Tensioner | ● | ● | ● |
| Idle Pulley & Idle Pulley Bearings | ● | ● | ● |
| Flywheel (excluding teeth) | ● | ● | ● |
| Rocker Arms & Rocker Shafts | ● | ● | ● |
| Rocker Bearings | ● | ● | ● |
| Cylinder Head Valves | ● | ● | ● |
| Valve Seals & Valve Seats | ● | ● | ● |
| Valve Lifters & Valve Springs | ● | ● | ● |
| Valve Retainers | ● | ● | ● |
| Push Rods | ● | ● | ● |
| Water Pump | ● | ● | ● |
| Oil Pump & Oil Pump Housing | ● | ● | ● |
| Harmonic Balancer | ● | ● | ● |
| Oil Pan (excluding drain plug threads) | ● | ● | ● |
| Intake Manifold | ● | ● | ● |
| Exhaust Manifold (excluding manifold & converter assembly) | ● | ● | ● |
| Valve Covers | ● | ● | ● |
| Engine Mounts | ● | ● | ● |
| Diesel Fuel Injection Pump | ● | ● | ● |
| Diesel Vacuum Pump | ● | ● | ● |
| Seals & Gaskets* | ● | ● | ● |


|  TURBOCHARGER /SUPERCHARGER | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Turbocharger/Supercharger Housing & all internal parts | ● | ● | ● |
| Blowout Valves | ● | ● | ● |
| Intercooler | ● | ● | ● |
| Seals & Gaskets* | ● | ● | ● |


|  TRANSMISSION (Automatic and Standard) | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Transmission case (if damaged from within) & all internal parts | ● | ● | ● |
| Input Shaft | ● | ● | ● |
| Master Clutch Cylinder | ● | ● | ● |
| Torque Converter | ● | ● | ● |
| Vacuum Modulator | ● | ● | ● |
| Transmission Mounts | ● | ● | ● |
| Oil Pan | ● | ● | ● |
| Seals & Gaskets* | ● | ● | ● |


|  TRANSFER CASE | Powertrain | Select Plus | Ultimate |
|--|------------|-------------|----------|
| Transfer Case (if damaged from within) & all internal parts | ● | ● | ● |
| Encoder Motor | ● | ● | ● |
| Seals & Gaskets* | ● | ● | ● |

|  DRIVE AXLE (Front and Rear) | Powertrain | Select Plus | Ultimate |
|--|------------|-------------|----------|
| Final Drive Housing | ● | ● | ● |
| Drive Axle Case (if damaged from within) & all internally lubricated parts. | ● | ● | ● |
| Differential Cover | ● | ● | ● |
| Axle Shaft | ● | ● | ● |
| Drive Shaft Universal Joint | ● | ● | ● |
| Wheel Bearings | ● | ● | ● |
| Hub Bearing Assembly (unless the failure is caused by an anti-lock braking system) | ● | ● | ● |
| Tapered Wheel Bearings | ● | ● | ● |
| Locking Hubs | ● | ● | ● |
| Drive Shaft | ● | ● | ● |
| CV (Constant Velocity) Joints | ● | ● | ● |
| Drive Line Actuators | ● | ● | ● |
| CV Boots | ● | ● | ● |
| Seals & Gaskets* | ● | ● | ● |


*Seals & Gaskets coverage means coverage of excessive leakage for all seals and gaskets listed for the plan selected that contain fluids or lubricants.


|  FRONT WHEEL STEERING | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Steering Box & all internal parts | ● | ● | ● |
| Rack & Pinion Gear | ● | ● | ● |
| Power Steering Pump | ● | ● | ● |
| Power Steering Hoses | ● | ● | ● |
| Steering Spindles | ● | ● | ● |
| Pitman Arm | ● | ● | ● |
| Idle Arm | ● | ● | ● |
| Center Link | ● | ● | ● |
| Upper Steering Column Shaft | ● | ● | ● |
| Relays | ● | ● | ● |
| Sensors | ● | ● | ● |
| Seals & Gaskets* | ● | ● | ● |

|  BRAKES | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Master Cylinder | ● | ● | ● |
| Vacuum Assist Booster | ● | ● | ● |
| Hydro Assist Booster | ● | ● | ● |
| Disc Brake Caliper | ● | ● | ● |
| Wheel Cylinders | ● | ● | ● |
| Compensating Valve | ● | ● | ● |
| Metal Brake Hydraulic Lines | ● | ● | ● |
| Combination Valve | ● | ● | ● |
| Seals & Gaskets* | ● | ● | ● |


|  ELECTRICAL | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Alternator | ● | ● | ● |
| Digital Instrument Cluster | ● | ● | ● |
| Instrument Panel Printed Circuit Board | ● | ● | ● |
| ECM & TIPM | ● | ● | ● |
| Voltage Regulator | ● | ● | ● |
| Starter Motor | ● | ● | ● |
| Starter Solenoid | ● | ● | ● |
| Starter Drive | ● | ● | ● |
| Factory Engine Compartment Wiring Harness | ● | ● | ● |
| Electronic Ignition Module | ● | ● | ● |
| Distributor Pick-up Coil | ● | ● | ● |
| Ignition Switch | ● | ● | ● |
| Ignition Lock Cylinder | ● | ● | ● |
| Ignition Coils | ● | ● | ● |
| Front & Rear Wiper Motor | ● | ● | ● |
| Washer Pump & Switch | ● | ● | ● |
| Manually Operated Electrical Switches | ● | ● | ● |


SCHEDULE OF *COVERAGE* includes parts and labour for the following components:


|  ELECTRICAL (Cont.) | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Body Computer & Control Module | | ● | ● |
| Powertrain Control Module | | ● | ● |
| Stop Lamp Switch | | ● | ● |
| Headlamp Switch & Motor | | ● | ● |
| Turn Signal Switch | | ● | ● |
| Heater & Air Conditioning Control Assembly | | ● | ● |
| Blower Motor Resistor | | ● | ● |
| Horns | | ● | ● |
| Factory Installed Cruise Control Module | | ● | ● |
| Cruise Control Transducer | | ● | ● |
| Cruise Control Servo & Amplifier | | ● | ● |
| Cruise Control Engagement Switch | | ● | ● |
| Power Vent Window Motors | | ● | ● |
| Power Window Motor (excluding regulators) | | ● | ● |
| Power Window Switch | | ● | ● |
| Serviceable Power Seat Motors (excluding frame/base assembly) | | ● | ● |
| Power Seat Switch | | ● | ● |
| Power Mirror Motor (excluding assemblies) | | ● | ● |
| Power Mirror Motor Switch | | ● | ● |
| Power Antenna Motor (excluding mast) | | ● | ● |
| Convertible Top Motor | | ● | ● |
| Serviceable Sun Roof Motor (excluding frame assembly) | | ● | ● |
| Rear Defogger Switch | | ● | ● |
| Rear Window Defroster Grid (excluding glass) | | ● | ● |
| Power Door Lock Actuator & Switch | | ● | ● |


|  AIR CONDITIONER | Powertrain | Select Plus | Ultimate |
|--|------------|-------------|----------|
| Condenser | | ● | ● |
| Compressor | | ● | ● |
| Clutch Assembly & Pulley | | ● | ● |
| A/C Lines & Hoses | | ● | ● |
| Evaporator | | ● | ● |
| High/Low Compressor Cut-off Switch | | ● | ● |
| Expansion Valve | | ● | ● |
| Pressure Cycling Switch | | ● | ● |
| Orifice Tube | | ● | ● |
| Seals & Gaskets* | | ● | ● |


*Seals & Gaskets coverage means coverage of excessive leakage for all seals and gaskets listed for the plan selected that contain fluids or lubricants.


|  FUEL SYSTEM | Powertrain | Select Plus | Ultimate |
|--|------------|-------------|----------|
| Fuel Pump | | ● | ● |
| Diesel Injectors/Nozzles | | ● | ● |
| Fuel Tank | | ● | ● |
| Mechanical Fuel Tank Sending Unit | | ● | ● |
| Fuel Rail | | ● | ● |
| Fuel Pressure Regulator | | ● | ● |
| Metal Fuel Delivery Lines | | ● | ● |
| Fuel Tank Selector Valve | | ● | ● |


|  FRONT & REAR SUSPENSION | Powertrain | Select Plus | Ultimate |
|--|------------|-------------|----------|
| Upper & Lower Control Arms | | ● | ● |
| Control Arm Shafts/Bushings | | ● | ● |
| Upper & Lower Ball Joints | | ● | ● |
| Torsion Bars & Mounts/Bushings | | ● | ● |
| Stabilizer Bar (excluding any electronic disconnect system) | | ● | ● |
| Stabilizer Links & Bushings | | ● | ● |
| King Pins | | ● | ● |
| Spindle & Spindle Support | | ● | ● |

|  HEATING & COOLING SYSTEM | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Heater Core | | ● | ● |
| Front & Rear Blower Motor | | ● | ● |
| Engine Cooling Fan & Motor | | ● | ● |
| Hydraulic Fan Clutch Hub | | ● | ● |
| Radiator | | ● | ● |
| Hot Water Valve | | ● | ● |

|  EMISSION SYSTEM | Powertrain | Select Plus | Ultimate |
|--|------------|-------------|----------|
| Air Pump | | ● | ● |
| Cam Shaft Sensor | | ● | ● |
| Canister Purge Solenoid | | ● | ● |
| Canister Vent Solenoid (excluding the canister filter assembly) | | ● | ● |
| Knock Sensor | | ● | ● |
| Crank Angle Sensor | | ● | ● |
| EGR Solenoid | | ● | ● |
| EGR Valve | | ● | ● |
| Idle Speed Control Motor | | ● | ● |
| Mass Air Flow Sensor | | ● | ● |
| Manifold Pressure Sensor | | ● | ● |

|  EMISSION SYSTEM (Cont.) | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| O2 (Oxygen) Sensor | | ● | ● |
| PCM Coolant Temperature Sensor | | ● | ● |
| Serviceable Throttle Position Sensor (TPS) | | ● | ● |
| Vacuum Pump | | ● | ● |
| Evaporator Vent Solenoid | | ● | ● |
| Air Fuel Ratio Sensor | | ● | ● |
| Emission System Coverage Extension Ultimate plans extend the period of coverage for the Emission System from an odometer reading of 100,000km to 140,000km. | | | ● |

|  ELECTRIC/HYBRID VEHICLES | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Batteries & Battery Packs (up to \$10,000, excludes battery degradation) | | | ● |
| Home Charging Unit (1 repair or replacement, up to \$800) | | | ● |
| All mechanical system parts or components are covered unless specifically listed as not covered. Some examples of extra-covered components are: | | | |
| Electric Power Control Modules | | | ● |
| Electric Motor Controller | | | ● |

|  ULTIMATE PARTS GROUP | Powertrain | Select Plus | Ultimate |
|---|------------|-------------|----------|
| Block Heater | | | ● |
| Transmission Cooler Lines | | | ● |
| Hub Bearing Assemblies | | | ● |
| Steering Wheel | | | ● |
| Power Steering Cooler | | | ● |
| ABS Sensor and Wiring Harness | | | ● |
| Park Brake Cables | | | ● |
| Complete Vehicle Wiring Harness | | | ● |
| Radio | | | ● |
| Rear Seat Media System | | | ● |
| Navigation Systems | | | ● |
| Window Regulators | | | ● |
| Heated Seats | | | ● |
| Daytime Running Light Module | | | ● |
| Fuel Level Sensor | | | ● |
| Fuel Gauge | | | ● |
| Coolant Reservoir | | | ● |
| Radiator Cap | | | ● |

BENEFITS



Canada & United States Coverage

F CPP covers your vehicle anywhere in Canada and in the United States.



Direct Response

F CPP will efficiently handle your claim. For authorized services, repair costs are paid directly to the repair facility, saving you from out-of-pocket expenses and the inconvenience of waiting for reimbursement.



Reduced Deductible

You can choose a deductible of either \$100 or \$200 for each repair visit, plus any applicable taxes, for all covered repairs. If the same component fails again, there will be no deductible for its repair or replacement. The selected deductible will be reduced by \$50 when repairs are performed at your selling dealer.



Experienced Based Refund (EBR)/ Guaranteed Price Rebate (GPR)

(Available on qualifying plans)

If the plan you choose includes EBR/GPR, you can request a refund as soon as the plan expires. Refunds are calculated based on the original amount you paid for the plan, up to a maximum of \$2,000, minus your deductible.



Road Service & Towing

If your vehicle cannot safely operate on its own, we will reimburse the cost of towing it to the dealer (up to \$240) or to another location (up to \$100). Additional services provided include mechanical first aid, tire assistance, battery service, fuel delivery, and locksmith services.



Rental

If a covered breakdown requires overnight repairs, we will reimburse you for receipted expenses to rent a replacement vehicle or cover your taxi or public transportation costs. You can receive up to \$75 per day, with a maximum reimbursement of \$375 per repair.



Trip Interruption

If you experience a covered breakdown while more than 100 km away from your home and your vehicle needs to be kept at a repair facility overnight, we will reimburse you for motel and restaurant expenses with receipts. You can receive up to \$150 per day, with a maximum reimbursement of \$450 per repair.



Mechanical Breakdown Contracts
Administrator / Obligor
First Canadian Repair Protection



Mechanical Breakdown Policies
Administrator / Underwriter
Millennium Insurance Corporation

320 Sioux Road
Sherwood Park, AB T8A 3X6

Toll-Free PH: 1-800-381-2580

Local PH: 780-410-4508

Email: MechanicalAdmin@firstcanadian.ca

***NOTICE:** The contents provided in this brochure are only a summary of certain terms and conditions of the plan. Please refer to the actual certificate for complete details of coverage and exclusions. Not all plans are available in all provinces, and specific provisions may vary based upon individual provincial requirements.